

Callaway  
V



**ALLSPORT** WATCH

## INTRODUCTION

The Callaway ALLSPORT Watch delivers elite performance on the course in a sporty, fashionable design. Hit more greens and minimize penalty strokes by knowing precise distances to the front, center, and back of the green, as well as distances to hazards and doglegs.

## SPECIFICATIONS

Product	Callaway AllSport Watch
# of Courses	35,000+
Battery	220mAh Lithium Ion Polymer
Battery Life	Up to 9 hours / Time Mode Only: Up to 30 Days
Weight	1.92 oz.
Display Size	1.28" (128 x128 pixels)
Band Length	10.25"
Waterproof	Yes 5 ATM Designation

## CHARGING

1. Attach the magnetic pins on the charging cord to the magnetic charging ports located on the back of the watch.
2. Make sure the pins are aligned, then insert the other end of the charging cord into a USB port or AC adapter (not included).



## BUTTON DESCRIPTION

- A. [ POWER ]** - **HOLD** to Power On/Off, **PRESS** to turn Backlight On/Off.
- B. [ BACK ]** - **PRESS** to return to previous screen, **PRESS** to toggle analog/digital time display while on **Time Screen**.
- C. [ UP ]** - Scroll Up
- D. [ OK ]** - **PRESS** to Toggle Screens, Select Options - **HOLD** to access **Main Menu**.
- E. [ DOWN ]** - Scroll Down



## DESCRIPTION OF TERMS

- **PRESS** - Press & Release button quickly.
- **HOLD** - Press & Hold button until desired screen appears or change happens.

## SET UP

1. **HOLD [ POWER ]** button until watch powers on.
2. **Language** - Use the [ UP/DOWN ] buttons to scroll through the language options then **Press & Release** the [ OK ] button to select.
3. **Set Time** - **PRESS [ OK ]** button to connect to the satellites (**must be outside**) and the watch will automatically set the correct date and time. (This could take a few minutes) **Press & Release** the [ OK ] button to continue.

**Note:** If the time is incorrect by an hour, **Daylight Savings Time** must be turned ON.

4. **Gender** - Use the [ UP/DOWN ] buttons to toggle between Male or Female, then **Press & Release** the [ OK ] button to select.
5. **Age** - Use the [ UP/DOWN ] buttons to scroll to your age then **Press & Release** the [ OK ] button to select.
6. **Unit** - Use the [ UP/DOWN ] buttons to scroll to the desired unit of measure, then **Press & Release** the [ OK ] button to select.
7. **Height** - Use the [ UP/DOWN ] buttons to scroll to your height, then **Press & Release** the [ OK ] button to select.
8. **Weight** - Use the [ UP/DOWN ] buttons to scroll to your weight, then **Press & Release** the [ OK ] button to select.
9. The watch will then return to the **Time Screen** & the set up process is complete.

## TURN ON/OFF DAYLIGHT SAVINGS

1. From the **Time Screen**, **Press & Release** the [ OK ] button.
2. **Press & Release** the [ Down ] button to scroll to **Settings**, then **Press & Release** the [ OK ] button to select.
3. **Press & Release** the [ OK ] button again to select **System**.

4. **Press & Release** the [ **Down** ] button to scroll to **Clock**, then **Press & Release** the [ **OK** ] button to select.
5. **Press & Release** the [ **Down** ] button to scroll to **Daylight Saving**, then **Press & Release** the [ **OK** ] button to select.
6. **Press & Release** the [ **OK** ] button then use the [ **Up / Down** ] buttons to toggle **ON/OFF**. **Press & Release** the [ **OK** ] button to save, then **Press & Release** the [ **BACK** ] button to exit.

## TIME MODE

1. While on the Time Screen, **PRESS** the [ **BACK** ] button to toggle between Analog or Digital Time Display.
2. **PRESS** the [ **POWER** ] button to turn Backlight on.
3. **PRESS** the [ **OK** ] button to access **Main Menu**.



## GOLF MODE

1. From the **Time Screen**, **PRESS** the [ **OK** ] button to access the **Main Menu**.
2. Use the [ **UP/DOWN** ] buttons to scroll to **Golf**, then **Press & Release** the [ **OK** ] button to select and continue to the **Golf Menu**.



- **Play Golf:** Select to start your round of golf.
- **Score History:** Select to view saved rounds of golf (see pg 10).
- **Scorecard:** Select to toggle scorecard on/off (see pg 10).
- **Shot Distance:** Select to toggle shot distance on/off (see pg 11).

## PLAY GOLF

1. Use the [ **UP/DOWN** ] buttons to scroll to **Play Golf**, then **Press & Release** the [ **OK** ] button to select.
2. Device will begin searching for satellite signal (**PRESS** the [ **OK** ] button to cancel).
3. Once satellite connection is established, the nearest golf courses will be listed. Use the [ **UP/DOWN** ] buttons to scroll to desired course, then **Press & Release** the [ **OK** ] button to select.

## ON THE COURSE

1. **Play Mode** will now display the distance to the Front, Center & Back edge of the green for the current hole.
2. **PRESS** [ **OK** ] button to toggle between **Hazard, Scorecard & Shot Distance** Screens.
3. To exit **Play Mode** at any time, **HOLD** the [ **OK** ] button.



## HAZARDS

**Note:** If no hazards are present on that hole, the hazard screen will be blank.

1. While in Play Mode, **PRESS** [ **OK** ] button to access the **Hazard Screen**.
2. Only 3 hazards will show at a time. If a hole has more than 3 hazards, scroll by using [ **UP / DOWN** ] buttons. (*Hazards that are behind you will not be displayed*).
3. To exit, **PRESS** [ **OK** ] button to view **Scorecard, Shot Distance** (if enabled), or return to **distances to the green**.



## SCORECARD

**Note:** **Scorecard** must be turned **On** in the Golf Menu (see pg. 4)

1. From the Hazard Screen, **PRESS [ OK ]** button to access **Scorecard**.
2. Use [ **UP/DOWN** ] buttons until number of total strokes for that hole is displayed.
3. **HOLD** the [ **DOWN** ] button to scroll to **Putts**, use [ **UP/DOWN** ] buttons until correct number of putts is displayed.
4. **HOLD** the [ **DOWN** ] button to scroll to **GIR** (Greens in Regulation). Use [ **UP/DOWN** ] buttons to select **Y/N** (Yes or No).
5. To exit, **PRESS [ OK ]** button to return to **Play Mode**.



↑ 02 PAR 4

Score	4
Putt	2
GIR	N
Total	9 +1

## SHOT DISTANCE

**Note:** **Shot Distance** must be turned **On** in **Settings**.

1. **PRESS [ OK ]** button to access **Shot Distance**.
2. As you travel to your ball, the distance will begin calculating.
3. Once you arrive at your ball, the distance displayed is the distance of your previous shot (the distance you traveled).
4. To reset, **PRESS** the [ **DOWN** ] button.
5. **PRESS [ OK ]** button to view next/previous screen.



## AUTO-HOLE ADVANCE

1. The device will automatically switch to the next hole if **Scorecard** is turned OFF. If **Scorecard** is turned ON, a score must be entered before the device will advance to the next hole.

## END ROUND

1. When finished with round, **HOLD [OK ]** button to return to **Main Menu**.
2. If **Scorecard** is turned on, use the[ **UP/DOWN ]** buttons to scroll to desired option, **PRESS [ OK ]** to select.
  - **Save & Exit** - Save **Scorecard**, end round, and return to **Golf Menu**.
  - **Discard & Exit** - Discard **Scorecard**, end round, and return to **Golf Menu**.
  - **Cancel** - Select to return to **Play Mode**.

## SCORE HISTORY

1. From the Golf Menu, use the **[UP/DOWN]** buttons to scroll to **Score History**, then **PRESS [OK]** to select.
2. Use the **[UP/DOWN]** buttons to scroll to the scorecard you would like to view, then **PRESS [OK]** to select.
3. Use the **[UP/DOWN]** buttons to view your score on the front nine (1-9), the back nine (10-18), or the entire round (1-18).
4. **PRESS** the **[OK]** button to view the breakdown of your round by hole.
5. To exit, **HOLD** the **[OK]** button to return to the previous screen.

## SCORECARD

1. From the **Golf Menu**, use the **[UP/DOWN]** buttons to scroll to **Scorecard**, then **PRESS [OK]** to select.
2. **PRESS** the **[OK]** button again, then use the **[UP/DOWN]** buttons to toggle on/off.
3. **PRESS** the **[BACK]** button to exit and return to the **Golf Menu**.

## SHOT DISTANCE

1. From the **Golf Menu**, use the **[UP/DOWN]** buttons to scroll to **Shot Distance**, then **PRESS [OK]** to select.
2. **PRESS** the **[OK]** button again, then use the **[UP/DOWN]** buttons to toggle on/off.
3. **PRESS** the **[BACK]** button to exit and return to the **Golf Menu**.

## RUNNING

1. Use the **[UP/DOWN]** buttons to scroll to **Running**, then **PRESS [OK]** to select.



2. The watch will start searching for Satellite signal. Once connected, **PRESS** the **[OK]** button and start your session.
3. Use the **[UP/DOWN]** buttons to scroll and view:

- Timer
- Distance
- Pace
- Calories
- Avg. Pace
- Stride Rate
- Heart Rate
- Avg. Heart Rate



4. **PRESS** the **[OK]** button to stop, then choose:
  - **Resume:** Continue your session.
  - **Save:** End session and save.
  - **Discard:** End session and don't save.
5. After ending your session you can view your stats, **PRESS** the **[BACK]** button to exit and return to the **Main Menu**.

## CYCLING

1. Use the **[UP/DOWN]** buttons to scroll to **Cycling**, then **PRESS [OK]** to select.



2. The watch will start searching for Satellite signal. Once connected, **PRESS** the **[OK]** button and start your session.
3. Use the **[UP/DOWN]** buttons to scroll and view:

- Timer
- Distance
- Pace
- Calories
- Avg. Pace
- Stride Rate
- Heart Rate
- Avg. Heart Rate



4. **PRESS** the **[OK]** button to stop, then choose:
  - **Resume:** Continue your session.
  - **Save:** End session and save.
  - **Discard:** End session and don't save.
5. After ending your session you can view your stats, **PRESS** the **[BACK]** button to exit and return to the **Main Menu**.

## SWIMMING

1. Use the **[UP/DOWN]** buttons to scroll to **Swimming**, then **PRESS [OK]** to select.



2. The watch will start searching for Satellite signal. Once connected, **PRESS** the **[OK]** button and start your session.
3. Use the **[UP/DOWN]** buttons to scroll and view:

- Timer
- Distance
- Pace
- Calories
- Avg. Pace
- Stride Rate
- Heart Rate
- Avg. Heart Rate



4. **PRESS** the **[OK]** button to stop, then choose:
  - **Resume:** Continue your session.
  - **Save:** End session and save.
  - **Discard:** End session and don't save.
5. After ending your session you can view your stats, **PRESS** the **[BACK]** button to exit and return to the **Main Menu**.

## TRAINING

1. Use the **[UP/DOWN]** buttons to scroll to **Training**, then **PRESS [OK]** to select.



2. Use the **[UP/DOWN]** buttons to scroll to **Running** or **Cycling**, then **PRESS** the **[OK]** button to select.
3. The watch will start searching for Satellite signal. Once connected, **PRESS** the **[OK]** button and start.
4. Use the **[UP/DOWN]** buttons to scroll and view:

- Timer
- Distance
- Pace
- Calories
- Avg. Pace
- Stride Rate
- Heart Rate
- Avg. Heart Rate



5. **PRESS** the **[OK]** button to stop, then choose:
  - **Resume:** Continue your session.
  - **Save:** End session and save.
  - **Discard:** End session and don't save.
6. After ending your session you can view your stats, **PRESS** the **[BACK]** button to exit and return to the **Main Menu**.

## TRIATHLON

1. Use the **[UP/DOWN]** buttons to scroll to **Triathlon**, then **PRESS [OK]** to select.



2. The watch will start searching for Satellite signal. Once connected, **PRESS** the **[OK]** button and start your session.
3. To toggle between **Running**, **Cycling**, and **Swimming**, **PRESS** the **[BACK]** button.
4. Use the **[UP/DOWN]** buttons to scroll and view:

- Timer
- Distance
- Pace
- Calories
- Avg. Pace
- Stride Rate
- Heart Rate
- Avg. Heart Rate



5. **PRESS** the **[OK]** button to stop, then choose:
  - **Resume:** Continue your session.
  - **Save:** End session and save.
  - **Discard:** End session and don't save.
6. After ending your session you can view your stats, **PRESS** the **[BACK]** button to exit and return to the **Main Menu**.

## HISTORY

1. From the **Time Screen**, **PRESS** the **[OK]** button to access the **Main Menu**.
2. Use the **[UP/DOWN]** buttons to scroll to **History**, then **PRESS** the **[OK]** button to select.



3. Use the **[UP/DOWN]** buttons to scroll to **Running, Cycling, Swimming, or Triathlon**, then **PRESS [OK]** to select.
4. Use the **[UP/DOWN]** buttons to scroll to the session you would like to view, then **PRESS [OK]** to select.
5. To exit, **PRESS** the **[BACK]** button.

## RECORDS

1. From the **Time Screen**, **PRESS** the **[OK]** button to access the **Main Menu**.
2. Use the **[UP/DOWN]** buttons to scroll to **Records**, then **PRESS [OK]** to select.



3. Use the **[UP/DOWN]** buttons to scroll to your personal best **Running, Cycling, or Swimming** sessions, then **PRESS [OK]** to select.
4. Use the **[UP/DOWN]** buttons to scroll to the **Record** you would like to view, then **PRESS [OK]** to select.
5. To exit, **PRESS** the **[BACK]** button.

## **OTHER**

1. From the **Time Screen**, **PRESS** the **[OK]** button to access the **Main Menu**.
2. Use the **[UP/DOWN]** buttons to scroll to **Other**, then **PRESS [OK]** to select.
3. Use the **[UP/DOWN]** buttons to scroll to the tool you would like to use, then **PRESS [OK]** to select.

**Alarm** - **PRESS [OK]** to select Edit, then **PRESS** the **[UP]** button to enable the Alarm (On). Then **PRESS [OK]**.

Use the **[UP/DOWN]** buttons to set the hour to the desired time, then **PRESS [OK]**.

Use the **[UP/DOWN]** buttons to set the minutes to the desired time, then **PRESS [OK]**.

Use the **[UP/DOWN]** buttons to select AM or PM, then **PRESS [OK]** **PRESS** the **[BACK]** button to save and exit. The Alarm is now set.

**Navigation** - **PRESS [OK]** to select New POI (Point of Interest). Then use the **[UP/DOWN]** buttons to change the Latitude value. **PRESS [OK]** to toggle to the next value.

After the Latitude/Longitude values are set, **PRESS [OK]**, then **PRESS [OK]** again to select save.

**Pedometer** - **PRESS [OK]** then start walking, your number of steps will be displayed. To exit, **PRESS** the **[BACK]** button.

**Bubble Level** - Use to test how level a surface is.

**Geolocation** - Use to find your Latitude/Longitude location (must be outside).

## SETTINGS

1. From the **Time Screen**, **PRESS** the **[OK]** button to access the **Main Menu**.
2. Use the **[UP/DOWN]** buttons to scroll to **Settings**, then **PRESS [OK]** to select.
3. Use the **[UP/DOWN]** buttons to scroll to the Setting you would like to change, then **PRESS [OK]** to select.

## SYSTEM

**Language** - Select from English, French, Spanish, German, Japanese, or Chinese.

**Clock** - Change from 12 or 24 hour clock, manually adjust the time and turn Daylight Savings Time On/Off.

**Backlight** - Set the amount of time the Backlight stays on.

**Alert** - Change the button feedback settings. Select from Sound, Light, or Vibrate (these can be selected in any combination).

**Unit** - Choose the unit of measurement (Metric system or Imperial).

**Smartband** - Turn Smartband On/Off (Bluetooth, Calories, Steps, and distance walked).

**Geolocation** - Change the format for displaying Latitude and Longitude locations.

**Key Lock** - Temporarily disable the buttons on the watch.

**Factory Reset** - Return the watch to factory settings.

## PERSONAL

**User Profile**- Change your gender, height, weight, and age.

**Bike Profile**- Change the size and weight of the bike you are using.

## SENSORS

**Heart Rate** - Use to connect to an external Bluetooth heart rate monitor.

## FREE APP

Search for **ALLSPORT** in the Google Play Store™ or iTunes™



Upload and track your Golf Scores, Running, Swimming, Cycling, and steps.

Receive text, call, and other Smartphone notifications on the watch (iPhone™ only).

**Note:** Compatibility depends on model of Smartphone and version of operating software. Features may vary or could be limited due to compatibility conflicts.

**Note:** Text, Call, and other Smartphone notifications are only compatible with iPhone iOS™ (Not for Android™).

For Apple™: Compatible with iOS 9.0 or above.

For Android™: Compatible with OS 5.0 or above.


\*ANDROID IS A TRADEMARK OF GOOGLE INC.

## BLUETOOTH PAIRING GUIDE


1. In order to pair your Callaway AllSport to your Bluetooth device, you must download the “**ALLSPORT APP**” from the app store. The Callaway AllSport is compatible with Apple™ and Android™ devices.
2. Once the app has been downloaded, make sure Bluetooth is enabled on your device & AllSport watch. After Bluetooth has been enabled, open the app. The following screen will appear with a list of the AllSport devices to pair with:

### • To enable Bluetooth on AllSport:


- From Time screen: **PRESS** the [UP ARROW] to switch to Bluetooth screen.
- Next, **PRESS [OK]**. This will highlight on/off.
- Use the [UP/DOWN] buttons to select between Bluetooth being on or off.
- After you have selected on or off, **PRESS [OK]**.
- To return to time screen, **PRESS** the [BACK] button.




3. Next, select “ALLSPORT” to sync with. Once the device is selected a blue check will appear next to the device name.




4. After the blue check appears, press “pair” in the bottom left of your screen. The following screen will be displayed after you’ve hit pair (for Apple™ Products): Select “pair” to sync with Bluetooth device.



5. Once you've hit pair, your device will sync with the ALLSPORT.




6. Once the pairing wheel disappears, tap the arrow in the middle of screen.




7. Once the device is paired correctly, the AllSport will vibrate once.
8. If you have any data saved on the AllSport before opening the app, the AllSport will quickly sync with the app to upload your information. Your saved data will appear on the app screen.
9. If you would like to check to ensure your AllSport is connected to your Bluetooth device, select the “i” icon in the upper right corner of your screen.



- Next, select “Bluetooth”



- The following screen will appear with the blue check next to the listed AllSport device. If the blue check is not there, select the AllSport device you would like to pair with and then press “pair”.
- When you hit “pair”, your AllSport device will vibrate once. This signifies your AllSport is successfully paired to your Bluetooth device.



## **WARRANTY POLICY**

This product is warranted to be free from defects for up to (1) year from the original purchase date. IZZO Golf cannot refund your purchase unless purchased directly from IZZO Golf. IZZO Golf will replace or repair any unit that is determined defective under normal use within the warranty period. Please call Customer Service at **888-606-4634** to request a Return Authorization. All defective products must be returned to:

**IZZO Golf**  
**Attn: Returns Dept.**  
**1635 Commons Parkway**  
**Macedon, NY 14502**

Please include a note with your Name, Address, Phone # and Return Authorization #. Your replacement will be shipped once we diagnose the returned unit.

**To register your product visit:**  
***[www.callawaydmd.com/registration](http://www.callawaydmd.com/registration)***

***If you have any other questions or concerns, please call 1-888-606-4634 or go to [www.callawaydmd.com](http://www.callawaydmd.com)***

## CAUTION

Global Position System (GPS) was developed and is managed by the United States Department of Defense (DOD) which is responsible for its normal operation and position precision control; the U.S. is entitled to affect function or position precision of the whole system without prior notification or announcement based on its political considerations or safety of national defense.

In order to use the device correctly and safely, you must be aware of the following information prior to operating the device:

- The device was only designed for the purpose of leisure and recreation and is not applicable for industrial or special measurement.
- The device is only an auxiliary device. IZZO Golf will not accept any legal liability for accidents due to mistaken operation, or any use of the device for measurement.
- Please do not try to disassemble the device or repair any part of the device discreetly.
- Please do not store the device in places exposed to direct sunlight or in extremely high temperatures.

© 2017 CALLAWAY GOLF COMPANY.

Callaway Golf and the Chevron device are trademarks of Callaway Golf Company. IZZO Golf is an official licensee of Callaway Golf Company.

