

SWAMI 6000 QUICK START



CHARGING

1. Insert the micro USB charging end into the Swami 6000 & then insert the USB end of the charging cord into a USB charging port or AC adapter (included). The recommended USB charging rate is 5V, 1A.
2. A complete full charge will take roughly 6 hours of charging time.



MAGNETIC BELT CLIP REMOVAL:

The Swami 6000 has a set of strong internal magnets which holds on the metal belt clip. The belt clip must be removed before being able to attach to a cart frame. To remove the belt clip:

1. With the unit vertical, rotate the belt clip 90 degrees in either direction.
2. Next, lift up on the top end of the clip & push down on the other end to lift off from the magnets.


NOTE: The internal magnets are very strong. A generous amount of force is required to separate the clip from the magnets

To attach, simply line up the square backing of the belt clip and let the magnets attract the backing.



BUTTON DESCRIPTION

- **[Enter] Button:** Hold to power on, press select options.
- **[Page] Button:** Press to toggle between Green, Hazards, and Scorecard in **Play Mode**. Press to return to the previous screen.
- **[Up] Button:** Press to scroll up, change holes.
- **[Down] Button:** Press to scroll down, change holes.



USING SWAMI ON THE COURSE

Select the **Play** option from the **Start Menu** and press **[Enter]**. The Swami 6000 will search for surrounding courses that the device supports. Use the **[Up]** and **[Down]** keys to select your golf course, then press the **[Enter]** button.

1. PLAY MODE



2. HAZARDS



3. SCORECARD



4. SHOT DISTANCE



1. **Play Mode** will now display the distance to the Front, Center & Back edge of the green for the current hole.
2. While in **Play Mode**, press the **[Page]** button to access the **Hazard Screen**. To return to the **Play Mode** screen (distances to green) Press **[Page]** again.
3. To access the Scorecard, press the **[Page]** button while on the **hazard screen**. Press the **[Up]** or **[Down]** buttons to enter your score, then press **[Page]** again to return to the **Play Mode** Screen (distances to green).
Note: Scorecard can only be used if turned ON in Settings.
4. While in **Play Mode**, press the **[Enter]** to access **Shot Distance Mode**, & then travel from where you hit your shot to your ball. The distance that the shot traveled will be displayed. To return to the **Play Mode** screen (distances to green), press the **[Enter]** button.
Note: Shot Distance Mode can only be used if turned ON in Settings.